

PÕLLUMAJANDUSREHVID KATALOOG 2017

Reff OÜ
 Vabaduse 26, Valga
 68204, Eesti
 Tel. 57 820 300
 E-mail: reff@reff.ee
www.reff.ee



Nimi	Mõõt/Mudel/Li Si
Cultor	10.0/80 - 12 AW-IMPL 11 12PR [125A8] TT
Cultor	10.0/80 - 12 AW IMPL-04 10 PR [117 A8] TL
Cultor	8.25 - 15 AW-IMPL 12 16PR TT
Cultor	12.5/80 - 15.3 AW-IMPL04 14PR [141A8] TL
Cultor	5.50 - 16 6PR AS FRONT 04 (82A/8) TT
Cultor	6.00 - 16 AS FRONT 04 8PR [88A6/80A8] TT
Cultor	6.00 - 16 AS FRONT 08P 8PR [100/88A8] TT
Cultor	6.00 - 16 AS FRONT 09 8PR [100/88A8] TT
Cultor	6.00 - 16 AS FRONT 13 8PR [80A8] TT
Cultor	6.50 - 16 AS FRONT 08 8PR [91A6/83A8] TT
Cultor	7.50 - 16 AS FRONT 08 8PR [108/95A8] TT
Cultor	7.50 - 16 AS FRONT 13 8PR [90A8] TT
Cultor	10.00 - 16 AS FRONT 10 8PR [118 A6/114 A8] TL
Cultor	13.0/65 - 18 AW-IMPL 04 16PR [143 A8] TL
Cultor	14.5/80 - 18 AW-IMPL 03 12PR TL
Cultor	6.00 - 19 AS FRONT 10 8PR [96 A6/88 A8] TT
Cultor	8.0 - 20 AS AGRI 06 8PR [111A6] TT
Cultor	7.50 - 20 AS FRONT 08 8PR [103A6/96A8] TT
Cultor	16.0/70 - 20 (400/70 - 20) AGRO-INDUSTRIAL 20 R1 14PR
Cultor	500/60 - 22.5 AS-IMPL 08 16PR [159 A8] TL
Cultor	12.4 - 24 AS AGRI 06 12 PR [128 A8] TT
Cultor	12.4 - 24 AS AGRI 19 12 PR [128 A8] TT
Cultor	12.4 - 24 AS AGRI 06 8 PR [120 A6/112 A8] TT
Cultor	16.9 - 24 AS AGRI 13 8 PR [133 A6/125 A8] TT

Cultor	9.5 - 24 AS AGRI 19 8 PR [112 A6/104 A8] TT
Cultor	9.5 - 24 AS AGRI 10 8 PR [112 A6/104 A8] TT
Cultor	11.2 - 24 AS AGRI 19 8 PR [116 A6/108 A8] TT
Cultor	11.2 - 24 AS AGRI 10 8 PR [116 A6/108 A8] TT
Cultor	12.4 - 24 AS AGRI 19 8 PR [120 A6/112 A8] TL
Cultor	13.6 - 24 AS AGRI 13 8 PR [120 A8/123 A6] TT
Cultor	14.9 - 24 AS AGRI 19 8 PR [128 A6/121 A8] TT
Cultor	14.9 - 24 AS AGRI 19 8 PR [128 A6/121 A8] TL
Cultor	14.9 - 26 AS AGRI 10 8PR [128A6] TT
Cultor	16.9 - 26 AS AGRI 10 10PR [142A6] TT
Cultor	18.4 - 26 12PR AS AGRI 19 [139A8] TL
Cultor	12.4 - 28 AS AGRI 19 8PR [118A6] TT
Cultor	14.9 - 28 AS AGRI 19 8PR [130A6] TT
Cultor	16.9 - 28 AS AGRI 13 10PR [131A8] TT
Cultor	16.9 - 28 AS AGRI 13 12PR [135A8] TT
Cultor	16.9 - 28 AS AGRI 13 12PR [135A8] TL
Cultor	8.3 - 28 AS AGRI 10 8PR [107A6] TT
Cultor	11.2 - 28 AS AGRI 19 8PR [118A6] TT
Cultor	13.6 - 28 AS AGRI 19 8PR [118A8] TT
Cultor	16.9 - 30 AS AGRI 13 14PR [137 A8]TT
Cultor	16.9 - 30 AS AGRI 13 8PR [129A8] TT
Cultor	18.4 - 30 AS AGRI 13 12PR [141A8] TT
Cultor	18.4 - 30 AS AGRI 13 8PR [141A8] TT
Cultor	8.3 - 32 AS AGRI 10 6PR [105A6] TT
Cultor	9.5 - 32 AS AGRI 13 6PR [110A6] TT
Cultor	12.4 - 32 AS AGRI 13 6PR [111A8] TT
Cultor	18.4 - 34 AS AGRI 19 8PR [142A6] TT
Cultor	18.4 - 34 AS AGRI 10 16PR [156 A8] TT
Cultor	18.4 - 34 AS AGRI 19 10PR [146A6] TT
Cultor	8.3 - 36 AS AGRI 10 6PR [98A6] TT
Cultor	9.5 - 36 AS AGRI 10 6PR [112A6] TT
Cultor	12.4 - 36 AS AGRI 13 6PR [121A6] TT
Cultor	13.6 - 36 AS AGRI 10 6PR [125A6] TT
Cultor	15.5 - 38 AS AGRI 15 8 PR [133A6] TT
Cultor	16.9 - 38 AS AGRI 13 8PR [133A8] TT
Cultor	14.9 - 38 AS AGRI 15 6PR [130A6] TT

Cultor	13.6 - 38 AS AGRI 13 6PR [A6] TT
Cultor	18.4 - 38 AS AGRI 19 10PR [148A6] TT
Cultor	320/70 R24 RADIAL 70 [116A8/116B] TL
Cultor	320/85 R24 (12.4 R24) RADIAL 85 [122 A8/119 B] TL
Cultor	380/70 R24 RADIAL 70 [125A8/125B] TL
Cultor	380/85 R24 (14.9 R24) RADIAL 85 [131 A8/128 B] TL
Cultor	16.9 R24 RADIAL S [134 A8] TL
Cultor	320/85 R28 (12.4 R28) RADIAL 85 [124 A8/121 B] TL
Cultor	340/85 R28 (13.6 R28) RADIAL 85 [127 A8/124 B] TL
Cultor	380/70 R28 RADIAL 70 [127A8/127B] TL
Cultor	380/85 R28 (14.9 R28) RADIAL 85 [133 A8/130 B] TL
Cultor	420/70 R28 RADIAL 70 [133A8/133B] TL
Cultor	420/85 R28 (16.9 R28) RADIAL 85 [139 A8/139 B] TL
Cultor	480/70 R28 RADIAL 70 [140A8/140B] TL
Cultor	11.2 R28 RADIAL S [116 A8] TL
Cultor	13.6 R28 RADIAL S [123 A8] TL
Cultor	420/85 R30 (16.9 R30) RADIAL 85 [140 A8] TL
Cultor	460/85 R30 (18.4 R30) RADIAL 85 [145 A8/145 B] TL
Cultor	480/70 R30 RADIAL 70 [141A8/141B] TL
Cultor	14.9 R30 RADIAL S [129 A8] TL
Cultor	12.4 R32 RADIAL S [130 A8] TL
Cultor	420/85 R34 (16.9 R34) RADIAL 85 [142 A8/139 B] TL
Cultor	420/85 R34 (16.9 R34) RADIAL 85 [142 A8/139 B] TL DA
Cultor	460/85 R34 (18.4 R34) RADIAL 85 [147 A8/144 B] TL
Cultor	480/70 R34 RADIAL 70 [143 A8/143 B] TL
Cultor	520/70 R34 RADIAL 70 [148A8/148B] TL
Cultor	13.6 R36 RADIAL S [127 A8] TL
Cultor	420/85 R38 (16.9 R38) RADIAL 85 [144 A8/141 B] TL
Cultor	460/85 R38 (18.4 R38) RADIAL 85 (144 A8/141 B) TL
Cultor	480/70 R38 RADIAL 70 [145B] TL
Cultor	520/70 R38 RADIAL 70 [150 A8/150B] TL
Cultor	520/85 R38 (20.8 R38) RADIAL 85 [155 A8/152 B] TL
Cultor	580/70 R38 RADIAL 70 [155A8/155B] TL
Cultor	20.8 R42 RADIAL S [156 A8/153 B] TL